Panasonic: change the date:

x101
press: program
*#
press: 1234
press: 0000
press: speakerphone
press: speakerphone
press: arrow to move to the right hand side
press: "auto ans" to change the month
press: "auto dail" to save